



MS20

Suction Filter for MS, MSE, MV, MVE

This manual corresponds to the following reference:

MS20

Packing List

The following items are included:



Suction Filter 1 unit






Features

Important:

Do not use sharp pointed objects to open the suction filter.



Maintenance

- Keep filters clean to ensure proper solder suction and replace them when necessary.
- Replace any defective or damaged piece. Use original JBC spare parts only
- Repairs should only be performed by a JBC authorized technical service.
- Maintenance must not be carried out by children unless supervised.

Specifications

MS20

Suction Filter for MS, MSE, MV, MVE

Ref · MS20

- Net Weight: 34.10 a / 0.08 lb

- Package Dimensions/Weight: 134 x 62 x 48 mm / 55.87 g 5.28 x 2.44 x 1.89 / 0.12 lb $(L \times W \times H)$

Complies with CE standards.

FSD safe.



Warranty

JBC's 2 year warranty covers this equipment against all manufacturing defects. including the replacement of defective parts and labour.

Warranty does not cover product wear or misuse.

In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased.



This product should not be thrown in the garbage.

In accordance with the European directive 2012/19/EU, electronic equipment at the end of its life must be collected and returned to an authorized recycling facility.









www.jbctools.com