
Packing List

For ref. MS10:





Manual 1 unit Ref. 0034152



MS10 Front Filters for MSE

MS10 filters are used with MSE-B.







www.jbctools.com



Replacement

Open the front lid of MSE by sliding down the side tabs. Remove the worn filter by pulling it upwards (1) out of the snap-fits of the seal.

Position the new filter so that the black side is facing down (2) and the ribs at its long side are pointing backwards (3), towards the transparent ribs of the lid (4).

With the filter positioned flat between the snap-fits, push it back (5) until it stops against the transparent ribs.

Make sure that the snap-fits of the seal are slot into the lateral recesses (6) of the filter frame. Close the lid by pressing against both upper corners until it clicks.

